MDG17PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS - IMAGE *2*

01 - TOP AND CONSOLE PARTS 3

02 - CABINET PARTS - IMAGE *5*

02 - CABINET PARTS 6

03 - BULKHEAD PARTS - IMAGE *8*

03 - BULKHEAD PARTS 9

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) - IMAGE *10*

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) 11

MDG17PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS - IMAGE



MDG17PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Instructions, Installation	W10135134	
	Tech Sheet	W10183571	
	Repair Parts List	W10135136	
2	Cover, Display	W10131114	
3	Screw, 8-18 X 1/2	W10131119	
4	Facia-Overlay	W10135181	
5	Screw, 8-32 X 3/8	W10142728	3370225
6	Screw, 6-32 X 1.00	W10137322	
7	Screw, 6-20 X 1/2	W10140652	
8	Bracket, Control	W10124214	
9	Deflector Switch Assembly	W10133515	
10	Push Button &	W10135233	
11	Push Button	W10131113	
12	Control Board	W10130081	
13	Spacer	W10133514	
14	Nut, 6-32	W10139046	
15	Shield, Probing	W10161476	
16	CONSOLE	W10137299	
17	Nut, 8 U-Type	W10131123	
18	Screw, 8-18 X 5/16	W10139210	
19	Panel, Rear (Upper)	W10177313	
20	Screw, 8-18 x 1/2	3390647	488729
21	Cover, Terminal Box	8317340	
22	Screw, 8-18 x 3/8	3390814	90767
23	Receptacle (2-Way)	717252	
24	Terminal	94614	
25	Meter Case	W10136645	
26	Receptacle (4-Way)	717315	
27	Housing, Connector	3395683	
28	Clip, Ground	357572	
29	Tie Cable	3391018	
30	Coin Drop Assy.	W10133242	
31	Top	W10136707	
32	Washer (2)	W10068270	
33	Hex Bar Bolt	W10137319	
34	Coin Optic Sensor Assembly	W10130178	
35	Screw, 6-20 X 1.00	W10142655	
36	Door, Service	3351136	
37	Connector 3-Circuit	3936144	
38	Switch-Vault & Service Door	W10131838	
39	Bracket, Service Door	W10133508	
40	Connector 3 Position	3403498	
41	Connector,	3403499	

MDG17PDAWW - Parts Lookup

42	Harness Wire Sensor Switch	W10139456	
43	Screw, 8-18 X 5/16	W10139210	
44	Plate Mounting	3347825	3353813
45	Screw, 10-16 x 3/4	98445	
46	Cushion, Meter Case	3954812	
47	Clip, Harness	3394427	
48	Transformer 120 To 22.5 Vac.	W10131839	
49	Screw, 8-18 x 5/16	8533971	90767
50	Harness, Main	W10130190	
51	Screw, 5/16 - 24 x 1.00	3349065	
52	Screw, 10-24 x 3/8	3400000	
53	Rfi-Filter Cpl.	8540229	8540230
54	Jumper-Line Filter	W10175650	

Our Mission Statement

WEB will be the premier provider of laundry services to multi-housing communities by supplying superior equipment at reasonable prices, responding to service requests within twelve working hours, and maintaining unmatched security and revenue accounting procedures.

We, the employees of WEB, pledge to honor our company's mission statement by adhering to the following promises:

We promise to keep WEB the leading provider of value in the industry by listening and responding to the needs of our customers.

We Promise to honor our commitments, whether verbal or written, in all our dealings with customers and suppliers.

We promise to continually strive to improve our level of performance by exceeding our customer's service expectations.

We Promise to continue extending a warm, friendly, enthusiastic, and courteous attitude toward our customers and among ourselves.

~The Employees of WEB Service Company, LLC

MDG17PDAWW - Parts Lookup

02 - CABINET PARTS - IMAGE



MDG17PDAWW - Parts Lookup

02 - CABINET PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Boot, Foot	3391943	
2	Cone, Wedge	356674	
3	Screw, 10-16 x 1/2	3400077	
4	Clip, Front Panel	3391846	
5	Switch, Broken Belt	8564010	
6	Screw, 6-20 x 7/8	697773	3395530
7	Cabinet	8310656	8527930
8	Foot, Dryer (Plastic)	3392100	49621
	Foot - Optional (Extended Length Package Of 2)	279810	
9	Clamp, Motor	660658	
10	Spring, Idler	3387374	
11	Retainer, Idler	3389420	
12	Plug, Multivent	697750	49252
13	Pulley Assembly	3388672	279640
14	Screw, 10-16 x 1	3391915	681615
15	Plate, Cover	3394331	
16	Wire, Belt Switch	W10167613	
17	Bumper	693152	
18	Washer, Thurst	233520	
19	Clip	297092	
20	Tri-Ring	690997	
21	Hinge And Pin	3389247	
22	Handle, Door	3389522	
23	Screw, 10-16 x 1/2	3390663	681414
24	Cage Nut 5/16 - 18	90406	
25	Screw, 8-18 x 1/2	3390647	488729
26	Nut, ``U``	3389249	
27	Motor Assembly (60 Hz.)	W10139766	
28	Clamp, Pipe	3387561	
29	Pulley 60 Hz	3389627	3394341
30	Belt, Drive	W10131172	
31	Clip, Door Hinge	3390902	
32	Bracket, Motor	W10135695	
33	Washer	3392186	4159590
34	Screw, 8-32 x 5/8	3393909	
35	Ignitor	686590	279311
36	Cord, Power	3401401	3401402
37	Screw, 8-18 x 3/8	3387057	90767
38	Bracket, Switch	8564011	
39	Bracket, Idler	W10141380	
40	Switch, Assembly	W10155571	
41	Door Switch Assembly	3406109	3406107
42	Screw, 6-20 x 1.00	W10002600	

MDG17PDAWW - Parts Lookup

43	Panel, Toe (Includes, Item. 17)	697215	3406797
44	Seal, Front Panel	3387242	
45	Screw, 8-18 x 1/2	342055	488627
46	Retainer	3388229	
47	Door, Rear	3392563	280083
48	Screw, 8-18 x 3/8	694091	
49	Door, Front	3387872	
50	Wire, Jumper	8539892	
51	Lower Front Panel	3393081	279722
52	Strike, Door	696144	279570
53	Screw, Ground 10-32 x 1/2	8533974	4331106
54	Catch, Door Assembly	3392538	279570
55	4``-90 Elbow	279731	49026
56	Seal, Door	3390735	
57	Burner Assembly 60 HZ. (Refer To Pages 8 & 9 For	W10135231	
58	Valve Gas 60 HZ. (Complete)	W10141728	
59	Lock-Top	345670	
60	Foam Seal Cabinet	W10157932	
61	Dryer Exhaust Kit (For Side & Bottom Venting)	279818	

10-Steps to Quality Customer Service

Step 1: See the person that called for service as well as the Manager / Office.

Step 2: Survey the laundry room - outside & inside.

Step 3: Systematically check-out machines.

Step 4: Diagnose machines marked out-of-order or reported not operating properly.

Step 5: Go to your vehicle for all parts/materials needed.

Step 6 Repair the machines.

Step 7: Clean everything up: machines, room and yourself.

Step 8: Complete all paperwork/order parts.

Step 9: Survey the room/machine and leave an "OK to Use" sign.

Step 10: See the manager/office before leaving the location.

WEB's "Service" keeps our customers happy!

MDG17PDAWW - Parts Lookup

03 - BULKHEAD PARTS - IMAGE



MDG17PDAWW - Parts Lookup

03 - BULKHEAD PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Shaft, R.H. Thread	8575324	
2	Drum Hole Plug	8066086	
3	Screw, 8-18 x 5/16	8533971	90767
4	Screw, 8-18 x 3/8	90767	
5	Air Duct Assembly	3394346	
6	Seal, Outlet Housing	697813	
7	Seal, Drum Front	697814	697813
8	Nut, 3/8 x 16 (R.H.)	3934666	W10080210
9	Exhaust Pipe	8066224	279936
10	Clip, Exhaust	8572105	
11	Screw, 10-16 x 13/16	3387230	
12	Spring, Lint Door	3394986	
13	Screw, 8-18 x 1/2	3390647	488729
14	Thermostat 155 F. (Electronic)	W10133284	
15	Clip, Spring	8066208	
16	Nut, 3/8-16 (L.H.)	W10001120	W10080190
17	Bulkhead, Rear	3387809	
18	Washer, Support	3387459	W10080960
19	Shaft, L.H. Thread	8575325	
20	Ring, Tri	690997	
21	Roller, Support	8536973	8536974
22	Screen, Lint	W10049370	W10120998
23	Housing, Outlet Assembly	8563755	
24	Seal, Cover Plate	697770	
25	Drum Complete	8318215	3978765
26	Screw, 11-16 x 3/4	W10109200	
27	Seal, Drum	W10166807	
28	Wire, Jumper	3401707	
29	Thermal-Cutoff (Includes Item. 38)	8573713	
30	Door, Lint Screen	8563758	
31	Screw, 8-15 x 1/2	487909	488729
32	Wheel, Blower	W10168564	
33	Thermostat	W10131836	
34	Housing, Blower	W10135254	
35	Lint Duct Assembly	8066168	W10128606
36	Funnel, Burner	8573824	
37	Sensor, Radiant	338906	
38	Thermostat 205 (96 C) High Limit	8573028	
39	Screw, 10-16 x 1/2	3357011	308685
40	Baffle, Drum	697693	W10113136
41	Bulkhead, Front	697557	
42	Grille, Outlet	8563756	
43	Thermal Fuse	3392519	

MDG17PDAWW - Parts Lookup

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) - IMAGE



MDG17PDAWW - Parts Lookup

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED)

Illus. Item	Description	MFG #	ALT MFG#
1	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White)	W10135231	
2	Tube, Burner	688617	693140
3	Bracket, Ignitor	694298	
4	Ignitor	686590	279311
5	Screw & Washer (8-32 x 5/8)	3393909	
6	Screw, 10-16 x 1/2	343641	681414
7	Base, Burner	3389871	
8	Screw, 10-16 x 1/2	3387057	90767
9	Orifice, Burner (Type 1)	234870	
	Orifice, Burner (Type 2)	234868	
10	Valve, Gas 60 Hz. (Complete)	W10141728	
11	Screw, 8-32 x 1/2	694421	
12	Bracket, Coil	694538	
13	Coil, 60 Hz. (2 Terminal) (Main)	694540	
14	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)	694539	
15	Leak, Limiter	694424	
16	Screw, Regulator Adjustment	694423	
17	Spring, Regulator	694422	
20	Plug, Pipe	239822	
21	Pipe, Gas Supply	W10110395	
22	Valve & Union Shut-Off	697441	
23	Pipe, Tail	3393767	
24	Nut, Compression	233076	
25	Clamp, Pipe	3387561	
26	Bracket, Support	3389889	
NA	Conversion Kit (Type 1 and 2) to Type L.P.G.	W10135245	
NA	Kit, Dryer Repair	4392067	
NA	Kit, Dryer Vent Testing	8522199	
NA	PAINT, TOUCH-UP (1/2oz.) (White)	72017	
NA	PAINT, PRESSURIZED SPRAY (12 oz.) (White)	350930	
NA	PAINT, PRESSURIZED SPRAY (12 oz.) (Primer)	350938	
NA	PAINT, BULK (1 qt.) (White (Uncut))	799344	

Ten Steps to Quality Customer Service

Step 1: See the person that called for service as well as the Manager/office.

Step 2: Survey the laundry room-outside and inside.

Before you reach the first machine you should know:

A. Condition of vent hoods.
B. Are instruction signs properly installed.
C. If there is water, oil or trash on the floor.
D. Brand of machines in the room plus vend price.
E. If machines are level and aligned

Step 3: Systematically check-out machines, checking for:

All Machines:

A. Condition of line cords-proper grounds and electrical polarity.
B. Coin-chute operation-sticky, free, decals.
C. Behind the machines-water, trash, lint, etc.
D. Secured meters, locks, covers, tops, front panels, consoles and backs.
E. Safety features-missing or loose back panels, end caps, outlet and wall switch covers and floor drain covers.
F. Chipped tops/graffiti/rust.
G. Noise level of machines in operation.

Washers:

A. Condition of fill hoses/faucets-leaks, bubbles, cracks, rust.
B. Lid switch operation/adjustment.
C. Tub and wash basket components-agitators, guards, rust, hoses.
D. Water temperature-when possible.
E. Console switches/lights.

Dryers:

A. Free timers.
B. Door operation-properly closing, hinges, catches, latches, handle, seals.
C. Inside dryer-drums, seals, rust, exhaust.
D. Lint screens-exhaust chambers, sharp edges.
E. Rotate drums-noisy rollers, broken belts, scraping.
F. Console switches
G. Safety features-door switch, etc.
H. Gas lines, shut-off valves, gas odors.
I. Vent system.

Step 4: Diagnose machines marked out-of-order or reported not operating properly.

Step 5: Go to your vehicle for all parts/materials needed.

Step 6 Repair the machines.

Step 7: Clean everything up: machines, room and yourself.

Step 8: Complete all paperwork/order parts.

Step 9: Survey the room/machine-leave an "OK to Use" sign.

Step 10: See the manager/office before leaving the location.

WEB's "Service" keeps our customers happy!

MDG22PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS - IMAGE *2*

01 - TOP AND CONSOLE PARTS 3

02 - CABINET PARTS - IMAGE *5*

02 - CABINET PARTS 6

03 - BULKHEAD PARTS - IMAGE *8*

03 - BULKHEAD PARTS 9

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) - IMAGE *11*

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) 12

05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED) - IMAGE *13*

05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED) 14

MDG22PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS - IMAGE



MDG22PDAWW - Parts Lookup

01 - TOP AND CONSOLE PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Installation Instructions	W10135154	
	Tech Sheet	W10166332	
	Parts List	W10135170	
2	Top	W10137411	
3	Harness, Main	W10111006	
4	Console (Outer)	W10137459	
5	Clip, Harness	3394427	
6	Bracket, Console	8565237	
7	Connector, Sensor	353424	
8	Terminal	94614	
9	Plug, Terminal	3936144	
10	TERMINAL	94613	596797
11	Screw, 8-18 x 1/2	3390647	488729
12	Console (Inner)	W10137427	
13	User-Interface Assembly	W10137416	
14	Screw, 3-24 x 1/32	489136	
15	Connector, (Motor)	3395683	
16	Ground Wire Assembly	W10188087	
17	Nut, 6-32	W10139046	
18	Hinge & Pin Assembly	8565018	
19	Screw, 8-18 x 1/2	342055	488627
20	Plate, Mounting	3347825	3353813
21	Screw, 10-16 x 3/4	98445	
22	Bracket, Top Panel (Left)	W10137445	
23	Screw, 8-18 x 1/16	W10015090	489442
24	Bracket, Top Panel (Right)	W10137444	
25	Meter Case	W10171128	
26	Coin Drop Assy.	W10133242	
27	Coin-Optic Sensor Assembly	W10130178	
28	Screw, 6-20 X 1.00	W10142655	
29	Hex-Bar Bolt	W10137319	
30	Washer	W10068270	
31	Switch-Vault Service Door	W10131838	
32	Bracket, Service Switch	W10133508	
33	Screw, 8-18 X 5/16	W10139210	
34	Wire, Harness Sensor Switch	W10139456	
35	Service Door Assembly	3351136	
36	Harness, Communication	W10166307	
37	Harness, Meter Case	W10166308	
38	Transformer, 120 To 22.5 (VAC)	W10131839	
39	Screw, 8-18 x 5/16	8533971	90767
40	Cushion, Meter Case	W10137448	
41	Screw, 5/16 x 1.00	3349065	

MDG22PDAWW - Parts Lookup

42	Cam-Lock	W10145154
43	Push Button	W10131113
44	Fascia-Console	W10137438
45	Fascia-Dispenser	W10137461
46	Insert	W10189313
47	Screw, 8-32 x 1/4	488234
48	Seal-Console	W10187276
49	Tab-Grounding	3373818
50	Washer, Brass	W10189075
51	Display Cover	W10131114
52	Screw, 8-32 x 3/64	W10137457

Our Mission Statement

WEB will be the premier provider of laundry services to multi-housing communities by supplying superior equipment at reasonable prices, responding to service requests within twelve working hours, and maintaining unmatched security and revenue accounting procedures.

We, the employees of WEB, pledge to honor our company's mission statement by adhering to the following promises:

We promise to keep WEB the leading provider of value in the industry by listening and responding to the needs of our customers.

We Promise to honor our commitments, whether verbal or written, in all our dealings with customers and suppliers.

We promise to continually strive to improve our level of performance by exceeding our customer's service expectations.

We Promise to continue extending a warm, friendly, enthusiastic, and courteous attitude toward our customers and among ourselves.

~The Employees of WEB Service Company, LLC

MDG22PDAWW - Parts Lookup

02 - CABINET PARTS - IMAGE



MDG22PDAWW - Parts Lookup

02 - CABINET PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Cover, Terminal Block	8317340	
2	Screw, 8-18 x 3/8	3390814	90767
3	Screw Ground	8533974	4331106
4	Panel, Side (R.H.)	8565048	
5	Switch, Broken Belt	8564010	
6	Clip, Toe Panel	8519459	
7	Panel, Side (L.H.)	8565054	
8	Foot, Dryer	3392100	49621
	Foot - Optional (Extended Length Package Of 2)	279810	
9	Clamp, Motor	660658	
10	Spring, Idler	3387374	
11	Retainer, Idler	3389420	
12	Plug, Multivent	697750	49252
13	Pulley Assembly	3388672	279640
14	Bracket, Gas Pipe	3978776	
15	Bracket, Switch	8564011	
16	Wire, Belt Switch	W10167613	
17	Screw, 8-18 x 1/2	343641	681414
18	Washer, Thrust	233520	
19	Assembly, Door Switch	8574875	
20	Tri-Ring	690997	
21	Cover-Plate	8066115	3394331
22	Ramp, Door	8565083	
23	Strike, Door	8565122	
24	Wire-Motor To-Belt-Switch	8539892	
25	Base, Cabinet	8565046	
26	Panel, Rear	8565059	
27	Motor Assembly 60 HZ.	W10139766	
28	Wire, Jumper (Broken Belt Switch)	3398948	
29	Pulley 60 HZ.	8578220	
30	Belt, Drive	W10131172	
31	Bracket, Burner	8529757	
32	Bracket, Motor	W10135695	
33	Cord, Power	3401401	3401402
34	4`` - 90 Elbow	49026	
35	Screw, 8-18 x 3/8	693995	489069
36	Exhaust Pipe & Bracket	8563747	
37	Exhaust Pipe (Short)	8563750	
38	Exhaust Pipe (Long)	8563749	
39	Idler Bracket	W10141380	
40	Toe Panel	8540621	
41	Screw, 8-18 x 5/16	8533971	90767
42	Screw, 6-20 x 1.00	W10002600	

MDG22PDAWW - Parts Lookup

43	Screw, 8-18 x 1/2	3390647	488729
44	Seal, Front Panel	3387242	
45	Screw, 10-16 X 1/2	3393008	308685
46	Control Board	W10166297	
47	Control Bracket	8563727	
48	Plug, Strip Front Panel	8565043	
49	Screw, 10-16 x 1/2	3357011	308685
50	Front Panel (Includes Illus. 44)	W10117421	
51	Switch, Assembly	W10155571	
52	Foam-Seal (IEC)	8318396	
53	Boot, Foot	3391943	
54	Cone Wedge	356674	
55	Stop, Top Panel	W10137398	
56	Screw, 8-18 x 1/16	W10015090	489442
57	Dryer Exhaust Kit (For Side & Bottom Venting)	279818	

10-Steps to Quality Customer Service

Step 1: See the person that called for service as well as the Manager / Office.

Step 2: Survey the laundry room - outside & inside.

Step 3: Systematically check-out machines.

Step 4: Diagnose machines marked out-of-order or reported not operating properly.

Step 5: Go to your vehicle for all parts/materials needed.

Step 6 Repair the machines.

Step 7: Clean everything up: machines, room and yourself.

Step 8: Complete all paperwork/order parts.

Step 9: Survey the room/machine and leave an "OK to Use" sign.

Step 10: See the manager/office before leaving the location.

WEB's "Service" keeps our customers happy!

MDG22PDAWW - Parts Lookup

03 - BULKHEAD PARTS - IMAGE



MDG22PDAWW - Parts Lookup

03 - BULKHEAD PARTS

Illus. Item	Description	MFG #	ALT MFG#
1	Shaft, R.H. Thread	8575324	
2	Screw, 8-18 x 1/2	3390647	488729
3	Door, Lint Screen	W10153413	
4	Thermal Fuse (91 C)	3392519	
5	Air Duct Assembly	3394346	
6	Seal, Outlet Housing	697813	
7	Seal, Drum Front	697814	697813
8	Nut,3/8 x 16(R.H.)	3934666	W10080210
9	Lint Screen	W10049370	W10120998
10	Lens, Drum Light	3402841	
11	Screw, 8-18 x 1/2	359625	487240
12	Clip, Exhaust Pipe	8572105	
13	Screw, 8-18 x 5/16	8533971	90767
14	Bracket-Bulkhead Upper Mounting	8571651	W10118337
15	Screw, 8-18 x 3/8	693995	489069
16	Nut, 3/8-16 (L.H.)	W10001120	W10080190
17	Bulkhead, Rear	8520836	
18	Washer, Support	3387459	W10080960
19	Shaft, L.H. Thread	8575325	
20	Ring, Tri	690997	
21	Roller, Support	8536973	8536974
22	Exhaust Pipe	8563728	
23	Housing, Outlet Assembly	W10153423	
24	Screw, 8-18 x 5/8	489463	
25	Complete Drum Assembly	W10153420	
26	Screw, 11-16 x 3/4	W10109200	
27	Seal, Drum	W10166807	
28	Clip-Spring	8066208	
29	Screw, 8-18 x 3/8	90767	
30	Channel, Bracket Rear Bulkhead	8519221	W10118335
31	Plug, Rear Bulkhead	8529007	
32	Wire Jumper	3401707	
33	Baffle, Drum	W10153409	
34	Bulkhead, Front	8565061	
35	Bracket, Drum Light	8578825	
36	Grille, Outlet	W10153412	
37	Wheel, Blower	W10168564	
38	Thermal Cut-Off	8573713	
39	Spring, Lint Screen Door	3394986	
40	Seal, Cover Plate	697770	
41	Screw, 8-18 x 1/2	695240	488729
42	THERMISTOR	8577274	
43	Screw, 8-15 x 1/2	487909	488729

MDG22PDAWW - Parts Lookup

44	Housing, Blower	8544362	
45	Lint Duct Assembly	8066168	W10128606
46	Funnel, Burner	8573824	
47	Thermostat, High-Limit 205 F (96 C)	8573028	
48	Sensor, Radiant	338906	
49	Screw, 10-16 x 1	3387230	

Ten Steps to Quality Customer Service

Step 1: See the person that called for service as well as the Manager/office.

Step 2: Survey the laundry room-outside and inside.

Before you reach the first machine you should know:

A. Condition of vent hoods.
B. Are instruction signs properly installed.
C. If there is water, oil or trash on the floor.
D. Brand of machines in the room plus vend price.
E. If machines are level and aligned

Step 3: Systematically check-out machines, checking for:

All Machines:

A. Condition of line cords-proper grounds and electrical polarity.
B. Coin-chute operation-sticky, free, decals.
C. Behind the machines-water, trash, lint, etc.
D. Secured meters, locks, covers, tops, front panels, consoles and backs.
E. Safety features-missing or loose back panels, end caps, outlet and wall switch covers and floor drain covers.
F. Chipped tops/graffiti/rust.
G. Noise level of machines in operation.

Washers:

A. Condition of fill hoses/faucets-leaks, bubbles, cracks, rust.
B. Lid switch operation/adjustment.
C. Tub and wash basket components-agitators, guards, rust, hoses.
D. Water temperature-when possible.
E. Console switches/lights.

Dryers:

A. Free timers.
B. Door operation-properly closing, hinges, catches, latches, handle, seals.
C. Inside dryer-drums, seals, rust, exhaust.
D. Lint screens-exhaust chambers, sharp edges.
E. Rotate drums-noisy rollers, broken belts, scraping.
F. Console switches
G. Safety features-door switch, etc.
H. Gas lines, shut-off valves, gas odors.
I. Vent system.

Step 4: Diagnose machines marked out-of-order or reported not operating properly.

Step 5: Go to your vehicle for all parts/materials needed.

Step 6 Repair the machines.

Step 7: Clean everything up: machines, room and yourself.

Step 8: Complete all paperwork/order parts.

Step 9: Survey the room/machine-leave an "OK to Use" sign.

Step 10: See the manager/office before leaving the location.

WEB's "Service" keeps our customers happy!

MDG22PDAWW - Parts Lookup

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED) - IMAGE



MDG22PDAWW - Parts Lookup

04 - W10135231 BURNER ASSEMBLY, OPTIONAL PARTS (NOT INCLUDED)

Illus. Item	Description	MFG #	ALT MFG#
1	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White)	W10135231	
2	Tube, Burner	688617	693140
3	Bracket, Ignitor	694298	
4	Ignitor	686590	279311
5	Screw & Washer (8-32 x 5/8)	3393909	
6	Screw, 10-16 x 1/2	343641	681414
7	Base, Burner	3389871	
8	Screw, 10-16 x 1/2	3387057	90767
9	Orifice, Burner (Type 1)	234870	
	Orifice, Burner (Type 2)	234868	
10	Valve, Gas 60 Hz. (Complete)	W10141728	
11	Screw, 8-32 x 1/2	694421	
12	Bracket, Coil	694538	
13	Coil, 60 Hz. (2 Terminal) (Main)	694540	
14	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)	694539	
15	Leak, Limiter	694424	
16	Screw, Regulator Adjustment	694423	
17	Spring, Regulator	694422	
20	Plug, Pipe	239822	
21	Pipe, Gas Supply	W10110395	
22	Valve & Union Shut-Off	697441	
23	Pipe, Tail	3393767	
24	Nut, Compression	233076	
25	Clamp, Pipe	3387561	
26	Bracket, Support	3389889	
NA	Conversion Kit (Type 1 and 2) to Type L.P.G.	W10135245	

MDG22PDAWW - Parts Lookup

05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED) - IMAGE



MDG22PDAWW - Parts Lookup

05 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

Illus. Item	Description	MFG #	ALT MFG#
1	Plug Strip (Inner Door)	8565119	
2	Door Hinge Assembly	8578887	
3	Assembly, Door Intermediate	W10137467	
4	Screw, 8-18 x 5/8	9742177	
5	Screw, 6-32 x 3/8	3400618	
6	Seal, Window	8579663	
7	Handle, Door (Includes Illus. 20.)	W10117477	
8	Screw, 10-24 x 3/64	W10159996	
9	Screw	3393258	3373329D
10	Door Assembly (Inner) (Includes Illus. 1 & 14)	8578933	8579113
11	Screw, 8-18 x 11/16	355515	
12	Door, Outer Ring	W10112916	
13	WINDOW	8565117	
14	Door Catch Assembly	690081	279570
15	Retainer-Lower	8519354	
16	Door, Intermediate	8580059	
17	SCREW	8534022	
18	Retainer, Upper	8519356	
19	Door Seal (Not Serviceable)		
20	Pad, Door Handle	W10112927	
NA	PAINT, TOUCH-UP (1/2oz.) (White)	72017	
NA	PAINT, PRESSURIZED SPRAY (12 oz.) (White)	350930	
NA	PAINT, PRESSURIZED SPRAY (12 oz.) (Primer)	350938	
NA	PAINT, BULK (1 qt.) (White (Uncut))	799344	
NA	Hold Down Kit	8529894	346764
NA	Kit, Dryer Vent Testing	8522199	
NA	Kit, Dryer Repair	80047	
NA	Dry Rack	8563738	W10121663

Our Mission Statement

WEB will be the premier provider of laundry services to multi-housing communities by supplying superior equipment at reasonable prices, responding to service requests within twelve working hours, and maintaining unmatched security and revenue accounting procedures.

We, the employees of WEB, pledge to honor our company's mission statement by adhering to the following promises:

We promise to keep WEB the leading provider of value in the industry by listening and responding to the needs of our customers.

We Promise to honor our commitments, whether verbal or written, in all our dealings with customers and suppliers.

We promise to continually strive to improve our level of performance by exceeding our customer's service expectations.

We Promise to continue extending a warm, friendly, enthusiastic, and courteous attitude toward our customers and among ourselves.

~The Employees of WEB Service Company, LLC